

Geng St arted User Guide

Last updated: 1/25/2018



Browser Compability



For best user experience, please use Google Chrome.

Tool



Enter your tool number.

Material



Enter or select a material

Material Subgroup



Enter or select a material subgroup.

Material Condion



If applicable, select a condition and/or adjust the hardness values

Operaon



Select your tool path.

Machine



Enter or select your Spindle and Holder from the drop downs.

Machine Specifics



Optional: Enter Max RPM/ Max IPM and adjust workholding for more precise recommendations.

Parameters



Optional: Adjust specific parameters to better reflect your application.

Adjusng P arameters



Optional: U pdate values in this column to adjust recommendations.

ADOC / RDOC Graphic



Optional: ADOC and RDOC values can also be updated using the sliders on the side and bottom of the ADOC/RDOC Adjuster

Tool Engagement Angle Graphic



Optional: Tool Engagement Angle can also be adjusted with the TEA graphic.

Recommendaons



Your customized recommendations appear once the first 4 sections are complete.

Refine your Parameters

Optional: optimize for tool life or production using the Speed & Feed dials.

Export your Recommendaons

Optional: Click PDF to download your recommended parameters.